ANIMATED FIGURE INSTRUCTIONS

Congratulations! You are the proud owner of a Life-Size Figure. Please read over the directions carefully before using your new figure.

Please keep these instructions for future reference because they contain important information.

PACKAGE CONTENTS

Base	1 piece
Torso	1 piece
Head	1 piece
Costume	1 piece
Broom	4 pieces
Hat	1 piece
Leg supports	4 pieces
Cape	1 piece
Base poles	4 pieces
Curving Pole	1 piece
Crossbar Support	1 piece
UL/CUL Listed Switching Adapter	1 piece

Input: 100-240V ~50/60Hz
Output: 6V ⎓ 1000mA

PREPARATION

Estimated assembly time: 15-20 minutes.
Before beginning assembly, remove all parts from carton. Compare parts list and diagram above. If any part is missing or damaged, do not attempt to assemble or use the product.

ASSEMBLY INSTRUCTIONS

1. Set base and pieces on a clear, flat surface and assemble leg supports as shown in illustration 1. If placed on uneven surface, please insert the four pieces base poles into the corners of base.
2. The character suit MUST be placed over the leg supports BEFORE the rest of the Crossbar Support is assembled.
3. Assemble the Crossbar Support as shown in illustration 1. Place curving pole into the hole located on top of crossbar support as shown in illustration 2.
4. Attach torso onto frame as shown in illustration 3.
5. Finish putting the character clothes on frame by pulling the arms gently through sleeves. Secure the suit in the back by loop fastener. Adjust as desired.
6. Assemble broom as illustration 4 shown, slide the broom through the left hand. Adjust as desired.
7. Attach head as shown in illustration 3, make sure it clicks securely into place. Put hat on top of the head, tie cape to neck and adjust as desired.
8. Connect control cord on base to match connection on torso.
9. Plug in adapter on base. **This power unit is intended to be correctly oriented in a vertical or floor mount position.**
10. Unplug adapter when not in use.



Illustration 1



Illustration 2



Illustration 3



Illustration 4

FIGURE FUNCTIONALITY

Two-way toggle switch is located on the back of body.
OFF: Slide switch to "OFF" position to deactivate the item.
SENSOR: Slide switch to "SENSOR" position, simply make a noise or wave hand near item in front of base or walk by to activate.

STORAGE

Do not discard box as it should be used for storage. Return all parts to the original packaging. Store in a cool, dry location.

TROUBLE SHOOTING

If you have assembled the Life-Size Figure according to the instructions, but the head does not function properly, the problem could be:

- The item is not securely plugged into a functioning wall outlet or extension cord
- The outlet or extension cord the unit is plugged into has no power
- The head may not be firmly attached; remove head and then reattach

FREQUENTLY ASKED QUESTIONS (FAQ's)

1. I switched Figure on and it does not work. What can I do?

- First, ensure that the unit is plugged in. Next, ensure the toggle switch is in the desired position. Third, ensure the outlet your unit is plugged into has power. Last, disconnect and reconnect head and check all adapter connections.

2. I see a hole on the back of body. What is it for?

- This can simply be ignored. This was designed for "In-Store" Demonstration, allowing the retailer to plug in a 'TRY-ME' button.

SAFETY WARNING: Remove all plastic fasteners and tags. These are part of the packaging and should be discarded.
For indoor use only. This item is not a toy and should be used for decorative purposes only.

WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: CAN ICES-3(B).

THESE INSTRUCTIONS APPLY TO THE FOLLOWING ITEM NUMBER

62376

Visit WWW.GEMMY.COM **for more information.**
©2014 GEMMY INDUSTRIES CORP.
117 WRANGLER DRIVE. SUITE 100
COPPELL, TX 75019 U.S.A.
1 (877) 250-9032
MADE IN CHINA / PRINTED IN CHINA